

YoCan®


# UNI 3.0




## Instruction Manual

### Specification:

Size: 42\*31\*75mm  
 Animation HD Screen Size: 1.93inch  
 Adjust height: >42mm  
 Diameter Range: 11-16mm  
 Coil Resistance: >0.8Ω  
 Battery Capacity: 650mAh  
 Voltage Range: 1.8-4.2V  
 Safety Cut-off: 15 Seconds  
 Charging Type: 5V/1A Type-C  
 Charging Time: 1.0h



### UNI 3.0 Exploded View:



- 1 -

### Package Content:

1x UNI 3.0 Device  
 1x Instruction Manual  
 1x Magnetic 510 Thread Adapter  
 1x Type-C Charging Cable

### How To Use:

- Use the included magnetic 510 thread adapter to connect the cartridge.
  - Adjust height: >42mm.  
Simply push the height adjustment button up or down to perfectly fits the cartridge.
  - Diameter Range: 11-16mm.  
Simply dial the diameter adjustment dial to perfectly fits the cartridge. Make sure your cartridge is locked in position.
  - Turn on/off: Quickly click the power button 5 times within 2 seconds.
  - Change UI Modes: There are 3 types of UI Mode, quickly click power button 3 times enter into UI select interface, click +/- button to select and then click power button 1 time to confirm.
  - 1.8V 10 Sec Preheat: Quick click the power button 2 times.
  - Adjust the voltage: Click +/- button.
  - Vaping: Press and hold the power button.
  - Reset Puff Counter: Click - and power button at the same time.
  - Charging: Type-C port. Fast charging not supported.  
Charging time around 1.0 hour, battery indicator goes off once fully charged.
- Notice: Auto shutdown after 1.0 hour.

- 2 -



www.yocan.com

Original and Exclusive Manufacturer:  
 Shenzhen Yocan Technology Co.,Ltd



Made in China

	Power On.
	Power OFF.
	Select UI Mode.
	Start heating.
	15s Safety Cut-off.
	Reset Puff Counter.
	Please charge the device.
	Short circuit.
	Charging.

- 3 -

### Caution:

Keep the device away from any environment involving strong acids, alkaline, combustible materials, water, or any other liquids. Do not keep in hot cars or store above the room temperature of 74°F. Do not use damaged batteries. If the battery casing is damaged, discontinue use and safely recycle the battery. Do not use the battery if contacts become exposed to solid or liquid matter. Shorts can result in fire or an explosion of a battery. Do not touch coils when hot. Severe burns can result. Do not touch hot material. Severe burns can result. If the device gets too hot in use, please stop using it for a while. Not intended for tobacco or nicotine use. Not an ENDS device.

### Disclaimers:

People under 21 years of age are not permitted to purchase or use this device. Non-smokers, children, and women breastfeeding should not use this product. The device is not a medical device and is not intended to diagnose, cure or prevent any diseases or other conditions. The manufacturers and sellers will not be responsible for any consequential or incidental damage resulting from the sale or use of any merchandise.

- 4 -